




# BLANCO



1




	مادخستس الال لابق لس غي
<b>BG</b>	Да се почиства преди употреба
<b>CN</b>	使用前请冲洗
<b>DK</b>	Skyl før brug
<b>DE</b>	Vor Gebrauch spülen
<b>EN</b>	Clean before use
<b>FI</b>	Pese ennen käyttöä

<b>FR</b>	Nettoyer avant utilisation
<b>NL</b>	Voor gebruik reinigen
<b>GR</b>	Πλύνετε πριν από τη χρήση
<b>IT</b>	Lavare prima dell'uso
<b>HR</b>	Isprati prije uporabe
<b>LT</b>	Pirms lietošanas nomazgāt
<b>LV</b>	Prieš naudojant išplauti


<b>NO</b>	Vask før bruk
<b>PL</b>	Przed użyciem oplotać
<b>PT</b>	Lavar antes de usar
<b>RO</b>	Spălați înainte de utilizării
<b>RU</b>	Перед использованием промыть
<b>SE</b>	Sköljes före användning
<b>RS</b>	Isprati pre upotrebe

<b>SK</b>	Pred použitím umyte
<b>SI</b>	Pomijte pred uporabo
<b>ES</b>	Limpiar antes de usar
<b>CZ</b>	Před použitím umyjte
<b>TR</b>	Kullanmadan önce yıkayın
<b>UA</b>	Перед використанням промити
<b>HU</b>	Használat előtt öblítse le


2




3



3a




3b



4



5



6

